

# Manual Pila



timberlab

natural outdoor solutions

[www.timberlab.eu](http://www.timberlab.eu)

Timberlab B.V.  
Harskamperweg 32  
6731 AB Otterlo

## Follow this installation guide for a safe installation.

### General

- Follow this installation guide for a safe installation.
- Installation and connection of the lighting armature should be done by a certified installer
- Disable main supply before starting installation activities!
- Timberlab is not responsible for adjustments or modifications on the armature
- The armature is not dimmable!
- The earthing will be (is) connected to the RVS lid
- We do not recommend the use of concrete mortar for filling in the area around the column. If necessary/derivable, depending on the type of soil a stabilising sand can be applied.

### Maintenance advice

The wood does not require any maintenance. In the course of time, the wood will grey in a natural way. If a treatment is chosen, a moisture regulating surface treatment should always be applied. Ask your supplier for advice! If desired, the LED module can be cleaned with a soft brush.

### Warranty

The product comes with a two-year guarantee. Wood is a natural product. This wood is, unless expressly stated otherwise, fresh, undried, sawn and/or planed (if applicable). No further woodworking was performed. There is always a chance of warping and/or (dry) cracking of the wood. This may occur upon delivery or later. This is not a production error but a natural characteristic of the wood. Warranties do not apply for this.

Product	Wood species	Certification	In ground/ post holder	Colour temperature	Version	Voltage	Variations
				K		VAC	
Pila (60)	Larch (1)	N/A (0)	L1+1000mm (00)	N/A (0)	32mm hole (0)	230V (1)	N/A (00)
	Chestnut (2)	FSC (1)	L1+PH07 (07)		with cable (1)		Socket (02)
	Oak (3)	PEFC (2)	L1+PH08 (08)				Connection box (08)
	Accoya (4)		L2+PH07 (37)				
			L2+PH08 (38)				

The product code is generated by selecting the options and taking the number in brackets ( ).




11-03-2022



## Pila incl cable


### 1. Drilling

Drill or dig holes in the ground.



### 2. Place

Place the Pila in the hole.




### 3. Digging

-Dig out to 40cm deep.

**Make sure there is no voltage on the ground cables**

-Place the ground cables




### 4. Connect

### 5. Finishing

-Straighten the pole with the help of a spirit level.


-Close the hole in the ground.



## Pila excl cable


### 1. Drilling

Drill or dig holes in the ground.



### 2. Place

Place the Pila in the hole.




### 3. Digging

-Dig out to 40cm deep.

**Make sure there is no voltage on the ground cables**

- Place the ground cables.

- Feed the cables through the Pila.



### 4. Connect

### 5. Finishing

- Straighten the pole with the help of a spirit level.

- Close the hole in the ground.

